

Sears Parts Listing for Model TABLE SAW - BT3000

The following pages are from the Sears site as of 1/16/2001.

I've modified some of the tables. For some reason, the parts listed as 'Replacement' appeared on every table.

Rich Carmack

Click on any of the below links to take you to the proper page


Section	Page
Unit Parts	2
Unit Parts Diagram	3
Sliding Miter Table	4
Rip Fence	5
Motor	6
Blade Guard	7
Replacement	8

Unit Parts ([Return to Menu](#))

Diagram Number	Part Number	Part Description
1	969214-001	MOTOR ASSEMBLY.
2	969157-001	OFF/ON SWITCH ASSEMBLY
3	969600-001	SHIM
4	969226-001	HEX NUT (5/8-18)
5	969101-001	SAW TABLE
6	969102-001	FRONT CABINET PANEL
7	969103-001	REAR CABINET PANEL
8	969104-001	RIGHT CABINET PANEL
9	969105-001	LEFT CABINET PANEL
10	969529-002	LOCKER BRACKET
11	661694-002	CLAMPER BRACKET
12	969548-002	DUST COVER
13	969176-001	MITER TABLE ASSEMBLY.
14	969113-001	CLAMP PLATE
15	969114-001	1/4" DOWEL PIN
16	969115-001	CLAMP
17	969193-001	SHIM
18	607406-003	HEX NUT (5/16-18)
19	969117-001	FRONT RAIL
20	969924-001	REAR RAIL
21	969251-001	RAIL HOLDER NUT (5/16)
22	969120-002	RAIL LOCKING CLAMP
23	969122-002	BEVEL GEAR
24	969123-002	SHAFT
25	969124-002	GEAR SHAFT
26	969125-002	HANDLE SHAFT
27	969126-001	GEAR RACK
28	969127-001	TILTING GEAR
29	969128-001	CLUTCH
30	969129-001	CAM
32	607406-006	HEX NUT (3/4-16)
33	661796-001	WASHER
34	969130-001	LOCKING LEVER
35	969131-003	BLADE ADJUSTMENT HANDLE
36	969136-001	GRIP SHAFT
37	969242-001	LOCK RING
38	969132-001	BLADE ADJ'M'T INNER GRIP
39	969222-001	SPRING
40	969221-001	SPRING
41	706382-359	WASHER
42	706382-360	WASHER
43	706382-357	WASHER
44	615570-007	HEX BOLT (5/16-18 X 1-1/8")
45	615570-015	HEX BOLT (5/16-18 X 5/8")
46	968705-007	SCREW (10-24 X 1/2" PAN HD.)
47	968705-009	SCREW (10-24 X 5/8" PAN HD.)
48	968703-005	SCREW (8-32 X 3/8" PAN HD.)
49	607406-005	HEX NUT (38-16)
50	969218-001	SET SCREW (1/4-20 X 3/8")
51	941401-018	ROLL PIN
52	941401-831	ROLL PIN
53	969134-001	NAME PLATE
54	969135-001	SCALE LABEL
55	969137-001	OUTLET (15 AMP SINGLE POLE)
56	969138-001	CORD
57	989001-001	CABLE CLAMP
58	969140-001	BEVEL INDICATOR
59	642149-001	WIRE NUT
60	643128-001	LOCK WASHER (8-32 HEX)
61	969142-001	CON DISC SPRING


62	969218-006	SET SCREW (10-24 X 1/4")
63	970091-001	DATA PLATE
64	615570-012	BOLT (1/4-20 X 1" HEX)
65	615570-011	BOLT (1/4-20 X 2" HEX)
66	622171-053	HEX NUT (1/4-20)
67	968705-004	SCREW (10-24 X 5/16" PAN HD.)
68	969230-001	PLUG SOCKET BOX (A)
69	969229-001	PLUG SOCKET BOX (B)
70	968702-009	SCREW (8-16 X 5/8" PAN HD.)
71	969545-002	LOCKER SUPT. F
72	969546-002	SUPPORT LOCK B
73	969218-004	SET SCREW (10-24 X 3/8")
74	969912-001	BLADE ADJUSTMENT HANDLE GRIP
75	968705-007	SCREW (10-24 X 1/2" PAN HD.)
76	969605-003	THROAT PLATE
77	969617-009	SCREW (10-24 X 5/8" FLAT HD.)
78	969220-002	CAP SCREW
79	703473-089	LOCK WASHER
80	969212-001	GUIDE HOLDER
81	969207-002	V BELT
82	969202-002	1/4" SPACER
83	969202-004	1/2" SPACER
84	969205-001	BLADE WASHER
85	968703-015	SCREW (8-32 X 1" PAN HD.)
86	969599-001	SHIM
87	614658-007	SCREW (8-32 X 3/4" PAN HD.)
88	941401-306	ROLL PIN
89	968705-015	SCREW (10-24 X 1" PAN HD.)
90	969730-001	END CAP F1 (FRONT LEFT)
91	969731-001	END CAP F2 (FRONT RIGHT)
92	969732-001	END CAP R1 (RIGHT REAR)
93	969928-001	END CAP R2(LEFT REAR)
94	969143-001	RIP FENCE ASSEMBLY
95	969165-001	BLADE GUARD ASSEMBLY
96	969172-001	ACCESSORY TABLE ASSEMBLY INCLUDES KEYS 42, 100 THROUGH 106, AND 111.
97	661797-001	WARNING LABEL
98	661809-001	DESCRIPTION LABEL
99	969121-001	KEY PLATE
None	4010300	METAL WORK STAND
None	4060300	LONG MITER/RIP FENCE KIT
None	4070300	DUST BAG
None	4070330	DADO THROAT PLATE
None	4710300	MITER CLAMPING KIT
None	4730300	WIDE TABLE KIT
None	4950300	ROUTER/JIG SAW MOUNTING KIT
None	612547-771	OWNER'S MANUAL
100	969173-001	ACCESSORY TABLE
101	969174-004	HANDLE SHAFT
102	969175-002	HANDLE
103	969216-001	SPRING PLATE
104	623111-001	RETAINING EXTENSION
105	644585-002	HEX NUT (1/4-20)
106	969220-002	CAPSCREW
107	706382-343	WASHER
108	661853-001	SPACER
109	621032-002	WASHER
110	661574-001	HANG TAG
111	661992-002	BACK-UP PLATE
112	622183-052	SCREW (10-24 X 3/4" FLAT HD.)
113	662080-001	BOLT HOLDER

Main Unit Diagram ([Return to Menu](#))




Sliding Miter Table [\(Return to Menu\)](#)

Diagram Number	Part Number	Part Description
1	969177-001	MITER TABLE TOP
2	969188-001	MITER FENCE
3	661811-001	PIVOT
4	969190-001	SAW GAGE
5	969191-001	MITER INDICATOR
6	969192-001	FENCE HOLDER
7	615570-010	BOLT (5/16-18 X 3-1/4" HEX HD.)
8	661797-001	WARNING LABEL
9	706382-357	WASHER
10	969194-001	ADJUSTING CLAMP
11	968702-009	SCREW (8-16 X 5/8" PAN HD.)
12	969227-001	SPRING PLATE
13	969225-001	STOPPER PLATE
14	969228-003	MITER BASE
15	969598-002	GUIDE BAR
16	969916-003	HOLDER PLATE
17	968705-007	SCREW (10-24 X 1/2" PAN HD.)
18	607617-003	O-RING
19	621721-010	WASHER
20	969502-001	ECC. SCREW (10-24)
21	969500-001	QUICK STOP
22	969501-002	ECC. SCREW (8-32)
23	621721-001	WASHER
24	703477-006	HEX NUT (ELASTIC STOP)
25	661844-001	SLIDE (A)
26	969503-001	SLOTTED NUT (10-24)
27	621032-002	LOCK WASHER
28	661845-001	SLIDE (B)
29	969218-005	SET SCREW (10-24 X 1/4" HEX SOCKET)
30	969915-001	MITER LOCKING CLAMP
31	969114-002	DOWEL PIN (1/4 X 3/4)
32	661698-001	SLIDE PLATE
None	4060300	LONG MITER/RIP FENCE KIT
None	4070300	DUST BAG
None	4010300	METAL WORK STAND
None	4070330	DADO THROAT PLATE
None	4710300	MITER CLAMPING KIT
None	4730300	WIDE TABLE KIT
None	4950300	ROUTER/JIG SAW MOUNTING KIT
None	612547-771	OWNER'S MANUAL




Rip Fence Assembly ([Return to Menu](#))

Diagram Number	Part Number	Part Description
1	969144-001	RIP FENCE
2	969145-001	FRONT BLOCK
3	969148-001	LOCKING HANDLE BOLT
4	969153-001	SCALE INDICATOR
5	968703-007	SCREW (8-32 X 1/2" PAN HD.)
6	610878-003	SCREW (1/4-20 X 5/8" BUTTON HD.)
7	706382-358	WASHER
8	969240-001	SLIDE
9	969146-002	ECCENTRIC ROLLER
10	969147-002	PIN
11	969150-001	PLATE
12	969154-001	ROLLER HOLDER
13	969155-001	FENCE ROLLER
14	969114-002	DOWEL PIN (1/4 X 3/4")
15	968704-006	SCREW (10-14 X 1/2" PAN HD.)
16	968703-005	SCREW (8-32 X 3/8" PAN HD.)
17	931055-821	WASHER
18	969156-001	ROD
19	969252-001	CLAMPER-A
20	969254-001	CLAMPER-B
21	969253-001	COMPRESSION SPRING
22	941401-833	ROLL PIN
23	969114-001	DOWEL PIN (1/4)
24	607067-007	SCREW (10-24 X 1" PAN HD.)
25	969912-002	LOCKING HANDLE GRIP
26	623019-004	RUBBER PLUG
27	706404-007	HEX NUT (8-32)




Motor Assembly ([Return to Menu](#))

1	969209-001	ARBOR
2	616452-010	WOODRUFF KEY (3/16")
3	969235-003	BALL BEARING (6003RR)
4	969203-001	BEARING PLATE
5	969210-002	ARBOR PULLEY
6	622167-068	RETAINING RING
7	969235-004	BALL BEARING (6002RR)
8	969235-005	BALL BEARING (6200ZZ)
9	968702-019	SCREW (8-16 X 1-1/2 PAN HD)
10	969211-001	ARMATURE PULLEY
11	969213-001	HOLDER
12	969235-001	BALL BEARING (6210 RR)
13	095112-000	RETAINING RING (C) S-1
14	968913-001	ARMATURE (INCLUDES KEYS 12, 13, & 15)
15	969235-002	BALL BEARING (6001 RR)
16	968946-001	FAN CASING
17	968921-001	FIELD
18	611658-005	MOTOR HOUSING
19	612567-005	BRUSH ASSEMBLY
20	611681-001	BRUSH TUBE
21	617800-002	BRUSH TUBE CLAMP
22	968702-005	SCREW (#8-16 X 3/8" PAN HD.)
23	968705-015	SCREW (#8-16 X 1" PAN HD.)
24	611715-001	END CAP
25	968702-009	SCREW (#8-16 X 5/8" PAN HD.)
26	623173-005	WIRE NUT
27	990499-019	CORD WITH STRAIN RELIEF



Blade Guard ([Return to Menu](#))

Diagram Number	Part Number	Part Description
1	968700-004	SCREW (6-19 X 5/16" PAN HD.)
2	969169-001	ANTI-KICKBACK FINGERS
3	662002-001	SPACER CAP
4	969608-001	TORSION SPRING
5	969233-010	PUSH NUT
6	969170-001	DOWEL PIN (.309 X 1-1/4")
7	969610-002	ARM
8	969612-001	COVER (CLEAR)
9	969170-002	DOWEL PIN (.309 X 1-3/4")
10	969168-002	RIVING KNIFE ASSEMBLY
11	931055-821	WASHER



Replacement Parts ([Return to Menu](#))

Diagram Number	Part Number	Description
None	612547-771	OWNER'S MANUAL
None	4060300	LONG MITER/RIP FENCE KIT
None	4070300	DUST BAG
None	4070330	DADO THROAT PLATE
None	4710300	MITER CLAMPING KIT
None	4730300	WIDE TABLE KIT
None	4950300	ROUTER/JIG SAW MOUNTING KIT
None	4010300	METAL WORK STAND
500	969196-001	SAW BLADE
501	969244-003	LARGE WRENCH
502	969244-004	SMALL WRENCH
503	820193-004	3/32" ALLEN WRENCH
504	820193-005	1/8" ALLEN WRENCH
505	820193-007	3/16" ALLEN WRENCH
506	820193-006	5/32" ALLEN WRENCH

